


V1.7

Unit:mm







## Installation Manual:

- 2 | The tube for connecting vice-machine to master machine in the same lane (CAT5 network cables\*3PCS, 2 \* 1.0mm line\*1PCS).
- 3 | TCP/IP ethernet cable for connecting access device to PC.
- 4 Control board.
- 5 •• Fixing the equipment with M12 X 100mm expansive bolt .